



# How to continue dimension in autocad?

## Description

After several searches on the internet on a question like How to continue dimension in autocad?, I could see the lack of information on CAD software and especially of answers on how to use for example AutoCAD. Our site CAD-Elearning.com was created to satisfy your curiosity and give good answers thanks to its various AutoCAD tutorials and offered free.

Engineers in the fields of technical drawing use AutoCAD software to create a coherent design. All engineers must be able to meet changing design requirements with the suite of tools.

This CAD software is constantly modifying its solutions to include new features and enhancements for better performance, more efficient processes.

And here is the answer to your How to continue dimension in autocad? question, read on.

## Introduction

1. Type DCO or DIMCONTINUE on the command line or command prompt.
2. Press Enter.
3. Select the continued dimension.
4. **Continue** specifying second extension line origin points, as shown in the below image:
5. Press Enter or Esc to exit.

You asked, how do I set continuous dimensions in **AutoCAD** 2016?

Also, what is a continuous dimension? Continuous dimensioning breaks one long **Dimension** into shorter segments that add up to the total measurement. The command is a variation of linear dimensioning in that existing dimensioning is continued or extended. A second Dimension is linked to an existing **Dimension** to create a dimensioning chain.

In this regard, how do you keep the same **dimension** when scaling in AutoCAD? This will show you how to change scale in AutoCAD without changing the dimension. How to scale down in AutoCAD – Window select the object(s) in **AutoCAD**, type SCALE, and then specify a number between 0 and 1. Hit Enter. The size of the object(s) will SCALE DOWN by that factor.

Moreover, what are running dimensions? A running **dimension** is a dimension that is taken from one end of a structure and provides multiple points in an increasing fashion. It is for baggages in an aircraft.

1. Click Annotate tab Dimensions panel Adjust Space. Find.
2. Select the dimension that you want to use as the base dimension when equally spacing dimensions.
3. Select the next dimension to align.
4. Continue to select dimensions and then press Enter.
5. Enter 0 and press Enter.

## Can dimensions be continuous?

Date dimensions and numeric dimensions can be discrete or continuous, and all measures can be discrete or continuous. After you drag a dimension to Rows or Columns, you can change the field to a measure just by clicking the field and choosing Measure.

## What is parallel dimensioning?

Parallel dimensioning is a type of linear dimensioning that measures and labels the absolute distance between two points, regardless of the relative position of the axes.

## What are continuous and discrete field types?

What is the difference between discrete and continuous data? Discrete data is a numerical type of data that includes whole, concrete numbers with specific and fixed data values determined by counting. Continuous data includes complex numbers and varying data values that are measured over a specific time interval.

## How do you scale a CAD drawing without changing dimensions?

## How do you prevent a specific dimension from changing when you edit other dimensions in the model?

## Why are my dimensions wrong in AutoCAD?

Check the units of the drawing are set correctly (enter the UNITS command). The units may have been changed from when the drawing was originally created. Check objects for Elevation or Start Z / End Z values (via Properties palette). Dimensioning from 2D to 3D space can throw off values.

## What are the 3 types of drawing dimensions?

Linear dimensions can be horizontal, vertical, or aligned.

## What is combined dimensioning?

Explanation: In chain dimension, the dimensions are arranged in a straight line. The type of dimensioning in which the dimensions are arranged parallel to each other is called a Parallel Dimension. The combination of both the type is called as a combined dimension.

## How do you show dimensions in engineering drawing?

Dimension lines are the thin continuous lines that show the extent and direction of the dimension. These lines should be placed 8mm to 10 mm away from the outline of the drawing and should be placed uniformly 6mm to 8mm from each other. The dimension values are preferably placed near the middle of the dimension lines.

## How do you align dimensions?

Hold down the CTRL key and select the remaining dimensions to align. You can select the additional dimensions individually or use region selection. You can also select non-dimensional objects, however, the alignment only applies to the selected dimensions. The selected dimensions are highlighted.

## What is aligned system of dimensioning?

Aligned System. In the aligned system, dimensions are aligned with the entity being measured. They are placed perpendicular to the dimension line such that they may be read from the bottom or right-hand side of the drawing sheet. Dimensions are placed at the middle and on top of the dimension lines.

## How do you align dimensions in isometric AutoCAD?

## What is continuous data?

Continuous data is data that can take any value. Height, weight, temperature and length are all examples of continuous data. Some continuous data will change over time; the weight of a baby in its first year or the temperature in a room throughout the day.

## What's the difference between discrete and continuous data?

Discrete data is the type of data that has clear spaces between values. Continuous data is data that falls in a constant sequence. Discrete data is countable while continuous "measurable. To accurately represent discrete data, the bar graph is used.

## What is a continuous date?

Continuous dates draw a quantitative axis for the date values. For example, the view below displays the sales as a function of a continuous order date and is color-encoded by category. As you can see, the color of the Order Date field changes from blue to green after it is converted to a continuous quantity.

## Wrap Up:

Everything you needed to know about How to continue dimension in autocad? should now be clear, in my opinion. Please take the time to browse our CAD-Elearning.com site if you have any additional questions about AutoCAD software. Several AutoCAD tutorials questions can be found there. Please let me know in the comments section below or via the contact page if anything else.

The article clarifies the following points:

- What is parallel dimensioning?
- What are continuous and discrete field types?
- How do you prevent a specific dimension from changing when you edit other dimensions in the model?
- Why are my dimensions wrong in AutoCAD?
- What are the 3 types of drawing dimensions?
- What is combined dimensioning?
- How do you align dimensions?
- How do you align dimensions in isometric AutoCAD?
- What is continuous data?
- What's the difference between discrete and continuous data?