



# How to solid fill an object in autocad?

## Description

If your question is How to solid fill an object in autocad?, our CAD-Elearning.com site has the answer for you. Thanks to our various and numerous AutoCAD tutorials offered for free, the use of software like AutoCAD becomes easier and more pleasant.

Indeed AutoCAD tutorials are numerous in the site and allow to create coherent designs. All engineers should be able to meet the changing design requirements with the suite of tools. This will help you understand how AutoCAD is constantly modifying its solutions to include new features to have better performance, more efficient processes to the platform.

And here is the answer to your How to solid fill an object in autocad? question, read on.

## Introduction

1. First set the layer that you want to use for your **solid** fill.
2. On the Home tab in the Draw panel, click Hatch.
3. In the Pattern panel, choose Solid.
4. If you have one closed area, you can just click inside it to pick an internal point.
5. Press Enter to end the HATCH command.

You asked, how do you fill an **object** in **AutoCAD**?

1. Click Home tab Draw panel Hatch.
2. On the Hatch Creation tab > Properties panel > Hatch Type list, select the type of hatch that you want to use.
3. On the Pattern panel, click a hatch pattern or fill.
4. On the Boundaries panel, specify the how the pattern boundary is selected:

Beside above, how do you fill Color in AutoCAD?

Furthermore, is there a **fill** option in AutoCAD? Controls the display of filled objects such as hatches, 2D solids, and wide polylines.

Also know, how do I make a solid drawing in **AutoCAD**?

1. If necessary, on the status bar click Workspace Switching and select 3D Modeling. Find.
2. Click **Solid** tab > Solid panel > Extrude. Find.
3. Select the objects or edge subobjects to extrude.
4. Specify the height.

Fills an enclosed area or selected objects with a hatch pattern, solid **fill**, or gradient **fill**.

## What is the use of solid command?

Here is another command that can sometimes be quicker than a hatch. Solid allows you draw an solid filled object using 3 or 4 points. For this example, use the same four lines that you drew for the Boundary exercise..

## How do you fill in a box in AutoCAD?

1. Go to the Draw panel on the Home tab.
2. You will see a "Hatch creation" tab.
3. Further specify the pattern on the Pattern panel.
4. Choose your desired method: "Pick Points" or "Select Boundary Objects".
5. After filling the area, hit "Enter" to apply the hatch.

## How do you fill a circle in AutoCAD?

## How do you hatch a 3D solid in AutoCAD?

## How do you fill extruded objects in AutoCAD?

## How do I fill a color in AutoCAD 2021?

Right-click in the drawing area, and choose Properties. In the Properties palette, click Color, and then click the down arrow. From the drop-down list, choose the color that you want to assign to the objects. Press Esc to remove the selection.

## How do I create a polyline solid in AutoCAD?

1. Click on the "Home"™ tab and go to the "Modify"™ panel.
2. On the command line type M for "Multiple"™ then select the polyline, spline, line, or arc to to be joined together and press "Enter"™.

## What is solid Modelling in AutoCAD?

**Solid Modeling** A solid model is a volume that represents a 3D object, and has properties such as mass, center of gravity, and moments of inertia. You can create 3D solids from primitive solids such as cones, boxes, cylinders, and pyramids, or by extruding, revolving, sweeping, or lofting closed 2D objects as shown.

## What is a solid in AutoCAD?

A primitive solid is a “building block”™ that you can use to work with in 3D. Rather than extruding or revolving an object, AutoCAD has some basic 3D shape commands at your disposal. From these basic primitives, you can start building your 3D models.

## How do I change my surface from 3D to solid?

1. Enter THICKEN on the command line.
2. Select the surface.
3. Enter a thickness value for the selected surface on the command line.
4. When prompted, choose whether to erase the defining surface or not.

## What is hatch and fill in AutoCAD?

The Hatch command in AutoCAD is used to fill patterns inside an enclosed area. The patterns are hatched, gradient, and solid fill. The gradient patterns are defined as a smooth transition between two colors. There are several hatch patterns available in AutoCAD.

## What is use of hatch command?

By: Apr 06 2022  
In-product view. Fills an enclosed area or selected objects with a hatch pattern, solid fill, or gradient fill. Choose from the available hatch patterns, or use the User Defined command option to create custom hatches.

## What are the 2 methods of hatching in AutoCAD?

There are three standard hatch types to chose from: pattern, solid, and gradient. Once you’ve selected your hatch type from one of those three, you can further customize and make it your own by changing the color, scale, angle, and transparency.

## How do you make a solid box?

1. Click Home tab Modeling panel Box. Find.
2. Specify the first corner, or enter c (Center) to specify the center point of the base.

3. At the Command prompt, enter c (Cube). Specify the length of the cube and a rotation angle. The length value sets both the width and height of the cube.

## How do I fill in AutoCAD 2018?

1. Click Home tab Draw panel Hatch.
2. On the Properties panel Hatch Type list, select the type of hatch that you want to use.
3. On the Pattern panel, click a hatch pattern or fill.
4. On the Boundaries panel, specify the how the pattern boundary is selected:

## Conclusion:

I sincerely hope that this article has provided you with all of the How to solid fill an object in autocad? information that you require. If you have any further queries regarding AutoCAD software, please explore our CAD-Elearning.com site, where you will discover various AutoCAD tutorials answers. Thank you for your time. If this isn't the case, please don't be hesitant about letting me know in the comments below or on the contact page.

The article provides clarification on the following points:

- What is the use of solid command?
- How do you fill in a box in AutoCAD?
- How do you fill a circle in AutoCAD?
- How do you hatch a 3D solid in AutoCAD?
- How do I create a polyline solid in AutoCAD?
- What is solid Modelling in AutoCAD?
- How do I change my surface from 3D to solid?
- What is hatch and fill in AutoCAD?
- What is use of hatch command?
- How do I fill in AutoCAD 2018?